


C1M1 Field Update Instructions




Go to <https://www.elkproducts.com/c1m1-downloads> and review the Readme file for details on how to Install the C1M1 Config Utility

1. Save any other files from the site to
C:\Program Files (x86)\Elk Products\C1M1 Config Utility
folder on your PC.
2. Connect the USB to USB Mini B Cable from your PC to the C1M1
USB Mini B Port located on the bottom of the unit.
3. Open the C1M1 Config Utility.



4. Click "Click to Connect" which should change to {Green} Connected.
5. Click on any Grey Area and press Ctrl+Alt+P

6. Click Tools
7. Click Programming > Update Firmware >
8. The App Update field should populate with the Firmware Update to support your C1M1 version. If not click "Browse for BIN Files" and navigate to the folder C:\Program Files (x86)\ElkProducts\C1M1 Config Utility
9. Select the file ---- If not sure which file contact ELK Tech Support 1-800-797-9355 M-F, 8-6:45PM EST for assistance.



10. Click "Update"
11. When complete click "Done"
12. ***** Wait about 3 Minutes *****
13. Power Down the C1M1
14. ***** Wait 30 seconds *****
15. Power the C1M1 back UP and let it reinitialize
16. Test by sending a Communication Test Signal